


# Quick Set-up

## Slimline Curve

## STEP 1


# Set the Clock

1



Press the '>' button twice to activate the row of icons at the top of the screen.

2



Press the '>' button repeatedly to move across to the 'clock' icon (next to the 'P' icon) and press 'OK'

3



Use the '+' and '-' buttons to select the correct hour and then press 'OK'.

4



Continue through the clock settings using the '-' and '+' buttons followed by 'OK'. These include the day of the week 1-7, day of the month, month of the year and year date respectively.

Please note: If you prefer to use manual mode the clock does not have to be set.

## STEP 2

# Set Comfort Mode Temperature

The Comfort Mode represents the higher temperature setting required when you most need a heat source during a 24 hour period. For example when you wake in the morning or in the evening when you return to your home.

1



Press the '>' button twice to activate the row of icons at the top of the screen

2



Press the '>' button to move across to the **'Sun'** icon (next to the moon crescent icon) and press **'OK'**

3



Press the '+' and '-' buttons to select the correct temperature for your Comfort mode followed by **'OK'**.

Please note: The comfort mode can be used as a simple on and off mode without setting a programme.

## STEP 3

# Set Reduced Mode Temperature


The Reduced Mode represents the lower temperature setting required when you least need a heat source during a 24 hour period. For example during the night or when you are away from your home.

1



Press the '>' button twice to activate the row of icons at the top of the screen

2



Press the '>' button to move across to the **'Moon Crescent'** icon (next to the sun icon) and press **'OK'**

3



Press the '+' and '-' buttons to select the correct temperature for your reduced mode followed by **'OK'**.

# Select a Factory Heating Programme


When setting your built-in heating programme your electric radiator will need to know when you want the 'Comfort Mode' (higher) temperature and when you want the 'Reduced Mode' (lower) temperature, through a 24 hour cycle beginning at midnight. The radiator will run the 'Comfort Mode' whilst the programme is active, and outside of these times your radiator will run on the 'Reduced Mode'.

1



Press the '>' button twice to activate the row of icons at the top of the screen

2



Press the '>' button to move across to the 'P' icon (next to the clock icon) and press 'OK' and a letter and number will be displayed.

3



Press the '+' button through the pre-programmed settings from P1 to P9 until you reach your chosen programme and press 'OK'

**\*Please check the full Instruction Manual to view the 9 factory heating programmes.**

We recommend creating your own bespoke programme for maximum energy efficiency. Please see full instruction manual for details on how to do this.